

1 VACUUMING AND ADDITIONAL CHARGE


CAUTION

(1) Do not purge the air with refrigerants but use a vacuum pump to vacuum the installation! There is no extra refrigerant in the outdoor unit for air purging!

(2) Use a vacuum pump for R410A exclusively. Using the same vacuum pump for different refrigerants may damage the vacuum pump or the unit.

- ### 1. VACUUM
- Remove the cap, and connect the gauge manifold and the vacuum pump to the charging valve by the service hoses.
 - Vacuum the indoor unit and the connecting pipes until the pressure gauge indicates -0.1 MPa (-76 cmHg).
 - When -0.1 MPa (-76 cmHg) is reached, operate the vacuum pump for at least 15 minutes.
 - Disconnect the service hoses and fit the cap to the charging valve to the specified torque.
 - Remove the blank caps, and fully open the spindles of the 2-way and 3-way valves with a hexagon wrench (Torque : 6 to 7 N · m (60 to 70 kgf · cm)).
 - Tighten the blank caps of the 2-way valve and 3-way valve to the specified torque.

Blank cap (2-way valve)	20 to 25 N · m (200 to 250 kgf · cm)
Blank cap (3-way valve)	30 to 35 N · m (300 to 350 kgf · cm)
Charging port cap	10 to 12 N · m (100 to 120 kgf · cm)



2. ADDITIONAL CHARGE

Refrigerant suitable for a piping length of 7.5 m is charged in the outdoor unit at the factory.

When the piping is longer than 7.5 m, additional charging is necessary. For the additional amount, see the table below.

Additional refrigerant	Pipe length (25 ft)	Pipe length				g/m (oz/ft)
		7.5 m (25 ft)	10 m (33 ft)	15 m (49 ft)	20 m (66 ft)	
Cooling model 18,000 BTU/h class 24,000 BTU/h class	None	50 g (1.8 oz)	150 g (5.3 oz)	250 g (8.9 oz)	20 g (0.71 oz)	
		50 g (1.8 oz)	150 g (5.3 oz)	250 g (8.9 oz)	20 g (0.71 oz)	
Heat & Cool model (Reverse cycle) 18,000 BTU/h class 24,000 BTU/h class	None	100 g (3.5 oz)	300 g (10.6 oz)	500 g (17.7 oz)	40 g (1.41 oz)	
		100 g (3.5 oz)	300 g (10.6 oz)	500 g (17.7 oz)	40 g (1.41 oz)	

CAUTION

(1) When moving and installing the air conditioner, do not mix gas other than the specified refrigerant (R410A) inside the refrigerant cycle.

(2) When charging the refrigerant R410A, always use an electronic balance for refrigerant charging (to measure the refrigerant by weight).

(3) When charging the refrigerant, take into account the slight change in the composition of the gas and liquid phases, and always charge from the liquid phase side whose composition is stable.

(4) Add refrigerant from the charging valve after the completion of the work.

(5) If the units are further apart than the maximum pipe length, correct operation can not be guaranteed.



6 GAS LEAKAGE INSPECTION

CAUTION

After connecting the piping, check the joints for gas leakage with gas leak detector.

10 POWER

WARNING

(1) The rated voltage of this product is 230V A.C. 50Hz.

(2) Before turning on the verify that the voltage is within the 198V to 264V range.

(3) Always use a special branch circuit and install a special receptacle to supply power to the room air conditioner.

(4) Use a circuit breaker and receptacle matched to the capacity of the room air conditioner.

(5) The circuit breaker is installed in the permanent wiring. Always use a circuit that can trip all the poles of the wiring and has an isolation distance of at least 3 mm between the contacts of each pole.

(6) Perform wiring work in accordance with standards so that the room air conditioner can be operated safely and positively.

(7) Install a leakage circuit breaker in accordance with the related laws and regulations and electric company standards.

CAUTION

(1) The power source capacity must be the sum of the room air conditioner current and the current of other electrical appliances. When the current contracted capacity is insufficient, change the contracted capacity.

(2) When the voltage is low and the air conditioner is difficult to start, contact the power company the voltage raised.

11 TEST RUNNING

Perform test operation and check items 1 and 2 below.

For the operation method, refer to the operating manual.

The outdoor unit may not run, depending on the room temperature. In this case, the TEST RUN signal is received during air conditioner operation (use a metallic object to short the two metal contacts under the battery compartment lid and send the TEST RUN signal from the remote control unit).

Fig. 42

Short the two metal contacts under the battery compartment lid.

Fig. 43

OPERATION lamp (Red)
TIMER lamp (Green)
SWING lamp (Orange)

MANUAL/AUTO

Operation can be checked by lighting and flashing of the display section OPERATION and TIMER lamps.

Perform judgment in accordance with the following.

• Test running

When the air conditioner is run by pressing the remote control unit test run button, the OPERATION and TIMER lamps flash slowly at the same time.

• Error

The OPERATION, TIMER and SWING lamps operate as follows (Table 9) according to the error contents.


7 HOW TO CONNECT WIRING TO THE TERMINALS

A. For solid core wiring (or F-cable)


- Cut the wire end with a wire cutter or wire-cutting pliers, then strip the insulation to about 25 mm (1 5/16") of expose the solid wire.
- Using a screwdriver, remove the terminal screw(s) on the terminal board.
- Using pliers, bend the solid wire to form a loop suitable for the terminal screw.
- Shape the loop wire properly, place it on the terminal board and tighten securely with the terminal screw using a screwdriver.

B. For strand wiring

- Cut the wire end with a wire cutter or wire-cutting pliers, then strip the insulation to about 10 mm (3/8") of expose the strand wiring.
- Using a screwdriver, remove the terminal screw(s) on the terminal board.
- Using a round terminal fastener or pliers, securely clamp a round terminal to each stripped wire end.
- Position the round terminal wire, and replace and tighten the round terminal screw using a screwdriver.



HOW TO FIXED CONNECTION CORD AND POWER CABLE AT THE CORD CLAMP



8 ELECTRICAL REQUIREMENT

• Electric wire size and fuse capacity:

MODEL	18,000 BTU class		24,000 BTU class	
	MAX.	MIN.	MAX.	MIN.
Power supply cord (mm ²)	3.5	2.5	4.0	3.5
Connection cord (mm ²)	2.5	2.5	2.5	2.5
Fuse capacity (A)	20	1.5	30	1.5

• Always make the air conditioner power supply a special branch circuit and provide a special breaker.

• Always use H07RN-F or equivalent as the power supply cord and the connection cord.

9 ELECTRICAL WIRING

CAUTION











(1) Match the terminal block numbers and connection cord colors with those of the outdoor unit. Erroneous wiring may cause burning of the electric parts.

(2) Connect the connection cords firmly to the terminal block. Imperfect installation may cause a fire.

(3) Always fasten the outside covering of the connection cord with the cord clamp. (If the insulator is chafed, electric leakage may occur.)

(4) Always connect the ground wire.

1. INDOOR UNIT SIDE



12 MOUNT THE COVER PLATE AND THE INTAKE GRILLE



1. MOUNT THE COVER PLATE (RIGHT)

(1) Cut a pipe exit hole in the right plate. This is only when the pipe exits from the right side (Fig. 46).

Fig. 46

(2) Insert the hinges on the bottom of the intake grille into the holes in the base assembly. Then mount the arms to the three areas on the top of the intake grille (Fig. 47).

Fig. 47



13 REMOTE CONTROL UNIT INSTALLATION

• Remote control unit settings

(1) Press the START/STOP button and display only the clock.

Fig. 50

(2) Press the MASTER CONTROL button continuously for more than five seconds to display the current signal code.


Fig. 51

(3) Change the signal code with the **OK** button (R-b-c-d).

Fig. 52

(4) Press the MASTER CONTROL button again to return to the clock display and change the signal code.

• Confirm the setting of the remote control unit signal code and the printed circuit board setting. If these are not confirmed, the remote control unit cannot be used to operate for the air conditioner.



Error contents	Error display		
	OPERATION (RED)	TIMER (GREEN)	SWING (ORANGE)
Indoor unit circuit board error	○	○	○
Indoor unit room temperature sensor opened	2 times ●	○	○
Indoor unit room temperature sensor short circuited	2 times ●	○	○
Indoor unit piping sensor opened	3 times ●	○	○
Indoor unit piping sensor short circuited	3 times ●	○	○
Indoor unit fan error	6 times ●	○	○

○ : Fast flashing ● : Slow flashing — : Off

CHECK ITEMS

(1) INDOOR UNIT

- Is operation of each button on the remote control unit normal?
- Does each lamp light normally?
- Do not air flow direction louvers operate normally?
- Is the drain normal?
- Is there any abnormal noise and vibration during operation?

(2) OUTDOOR UNIT

- Is there any abnormal noise and vibration during operation?
- Will noise, wind, or drain water from the unit disturb the neighbors?
- Is there any gas leakage?
- Do not operate the air conditioner in the test running state for a long time.

• For the operation method, refer to the operating manual and perform operation check.

14 CUSTOMER GUIDANCE

Explain the following to the customer in accordance with the operating manual:

- Starting and stopping method, operation switching, temperature adjustment, timer, air flow switching, and other remote control unit operations.
- Air filter removal and cleaning, and how to use the air louvers.
- Give the operating and installation manuals to the customer.
- If the signal code is changed, explain to the customer how it changed (the system returns to signal code A when the batteries in the remote control unit are replaced).

JM2	JM3	Remote control unit signal code
Connect	Connect	A (Primary setting)
Connect	Disconnect	B
Disconnect	Connect	C
Disconnect	Disconnect	D

