

ERROR DISPLAY

Troubleshooting check table

Operation lamp : Red lamp
 Timer lamp : Green lamp

Large division indication			Small division indication		
Error contents	LED indication		Error contents	LED indication	
thermistor error	RED lamp Green lamp	● (2 times) ○	thermistor error (room temp.)	RED lamp Green lamp	○ ● (2 times)
			thermistor error (heat exchanger)	RED lamp Green lamp	○ ● (3 times)
control unit error (indoor unit)	RED lamp Green lamp	● (4 times) ○	MANUAL AUTO button error	RED lamp Green lamp	○ ● (2 times)
			power source Hz decision error	RED lamp Green lamp	○ ● (4 times)
fan motor error (indoor unit)	RED lamp Green lamp	● (6 times) ○	lock error	RED lamp Green lamp	○ ● (2 times)
			rpm error	RED lamp Green lamp	○ ● (3 times)

● : 0.5s ON/OFF repeated
 ○ : 0.1s ON/OFF repeated

ENINDEL CLIMA